
 SERVICE BULLETIN	model number P-100, P-200, P-100M	bulletin number 00002
	for serial numbers	
	subject ADDITIONAL ALIGNMENT TEST	
	technical services approval <i>J. R. Thomas</i>	writer <i>J. R. Thomas</i>
engineering approval 	date 10-31-78	

ADDITIONAL TEST PROCEDURE DURING ALIGNMENT

To be performed while setting Minimum Expression Settings for BOTH the Bass and Treble sections of the piano, using alignment tape T-426, test 7.

Do step 9-51 thru 9-55 as described in the PIANOCORDER Reproducing System Installation and Field Service Manual. While doing STEP 9-56 and listening to operation, turn FORTISSIMO control on the PT-100 Tape Recorder to Maximum (clockwise) then Minimum (counter-clockwise) several times. If you hear loudness of the piano greatly increase and decrease, or if FORTISSIMO control acts like a volume control, tape recorder may be defective. Replace tape recorder and repeat test after re-aligning the total system.

A Division Of
SUPERSCOPE.
INC.